

USER MANUAL

READ THESE INSTRUCTIONS CAREFULLY

**BALLISTIC VEST NIJ4-III A, BLACK
+ LEVEL IV NIJ4-IV ICW CERAMIC PLATES**

—

BRUKERMANUAL

LES DISSE INSTRUKSENE NØYE

**BALLISTISK VEST NIJ4-III A, SORT
+ NIVÅ IV NIJ4-IV ICW KERAMISKE PLATER**



User Manual - English

READ THESE INSTRUCTIONS CAREFULLY

GENERAL

This body armor is manufactured from tested and proven ballistic material. Separate pockets are provided on the front and rear of the carrier to accommodate soft armor panels and hard ceramic ballistic plates, respectively.

This body armor is rated according to the internationally accepted Standard NJ0101.04 for ballistic testing and testing procedures on soft ballistic panels and ceramic plates. The soft panels affords Level 3A protection. In conjunction with (ICW) the addition of hard ceramic plates, protection increases to Level 4.

WARNING

This carrier offers no ballistic protection without ballistic panels being inserted.

DO NOT attempt to prove the effectiveness of the body armor.

Always remember that the body armor will only protect that part of the body which it covers.

Wearing the body armor will not make you immune to injury. Your best protection is **CAUTION**.

BLUNT TRAUMA: While the correct level of protection will prevent a bullet from penetrating the body, kinetic energy will dissipate into the tissue surrounding the impact, possibly resulting in blunt trauma that may cause fractures, bruising or lacerations.

WEARING INSTRUCTIONS

Hard ceramic plates must be inserted with the curves of the plates aligning with the body. Ballistic panels are secured in place with velcro flaps.

Soft body armor plates must not be exposed to direct sunlight as UV rays reduce ballistic properties.

Should the soft or hard armor be struck by a bullet or projectile, it must be replaced.

STORAGE INSTRUCTIONS

Treat and handle this equipment with extreme care and respect. Repeated use, drops, exposure to humidity or direct sunlight may reduce the life expectancy of the body armor and its ballistic qualities. Store in a dark place, avoid exposure to moisture. Store carrier and panels flat, or hanging vertically. Avoid stacking carriers on top of each other long-term.

CARE INSTRUCTIONS FOR CARRIER

1. Remove all ballistic panels from carrier.
2. Ensure hook and loop fasteners are in closed position during washing.
3. Only the outer vest (carrier) may be machine washed, using the permanent press cycle and warm water settings (apprx 100F/40C).
4. Use low-sudsing detergent according to manufacturers instructions.
5. **DO NOT BLEACH**
6. Carrier should be air dried only.
7. Carrier must be completely dry before re-inserting panels.

CARE INSTRUCTIONS FOR PANELS

Soft ballistic panel **COVERS ONLY** can be cleaned with a damp cloth. Wipe clean, do not soak and remove wet residues promptly.

Replace body armor if cover is torn or damages, side or shoulder flaps are missing, or there is any visible damage to ballistic panels.

WARRANTY

10 years from date of manufacture (se label inside carrier).

Brukermanual - Norsk

LES DISSE INSTRUKSENE NØYE

GENERELT

Denne kroppsbeskyttelsen er produsert av testet og påvist ballistisk materiale. Det er separate lommer på forsiden og baksiden av platebærerens for å romme myke skuddsikre paneler og harde keramiske ballistiske plater, henholdsvis.

Denne kroppsbeskyttelsen er vurdert i samsvar med den internasjonalt aksepterte standarden NJ0101.04 for ballistiske tester og testprosedyrer for myke ballistiske paneler og keramiske plater. De myke panelene gir nivå 3A beskyttelse. Sammen med (ICW) tillegg av harde keramiske plater øker beskyttelsen til nivå 4.

ADVARSEL

Denne platebærerens gir ingen ballistisk beskyttelse uten at ballistiske paneler er satt inn.

IKKE forsøk å bevise effektiviteten av kroppsbeskyttelsen.

Husk alltid at kroppsbeskyttelsen bare beskytter den delen av kroppen den dekker.

Kroppsbeskyttelsen gjør deg ikke immun mot skader. Din beste beskyttelse er **FORSIKTIGHET**.

STUMPT TRAUME: Mens riktig nivå av beskyttelse vil forhindre at et prosjektil trenger inn i kroppen, vil kinetisk energi spre seg i vevet rundt treffpunktet, noe som kan resultere i stumpt traume som kan forårsake abdominalsår som brudd, blåmerker eller kutt.

BRUKSINSTRUKSER

Harde keramiske plater må settes inn med platens kurver som formes etter kroppen. Ballistiske paneler festes på plass med borrelåsflappene.

Myke kroppsbeskyttelsesplater må ikke utsettes for direkte sollys, da UV-stråler reduserer de ballistiske egenskapene.

Hvis det myke eller harde ballistiske panelet blir truffet av en kule eller prosjektil, må panelet byttes ut.

OPPBEVARING

Behandle dette utstyret med ekstrem forsiktighet og respekt. Gjentatt bruk, fall, eksponering for fuktighet eller direkte sollys kan redusere levetiden til kroppsbeskyttelsen og dens ballistiske egenskaper. Oppbevar på et mørkt sted og unngå fuktighet. Oppbevar platebærer og paneler flatt eller heng dem vertikalt. Unngå å stable platebærere oppå hverandre over tid.

VEDLIKEHOLD AV PLATEBÆREREN

1. Fjern alle ballistiske paneler fra platebærerens.
2. Forsikre deg om at borrelåsene er i lukket posisjon under vask.
3. Kun den ytre vesten kan vaskes i maskin, bruk permanentpresssyklusen og varmt vann (ca. 40°C).
4. Bruk lite skummende vaskemiddel iht til produsentens instruksjoner.
5. **IKKE BENYTT BLEKEMIDDEL**
6. Platebærerens skal kun lufttørkes.
7. Platebærerens må være helt tørr før du setter inn panelene igjen.

VEDLIKEHOLD AV BALLISTISKE PANELER

Kun de **MYKE BALLISTISKE PANELENE** kan rengjøres med en fuktig klut. Tørk rent, ikke bløt og fjern gjenværende fuktrester umiddelbart.

Bytt ut kroppsbeskyttelsen hvis dekslet er revet eller skadet, side- eller skulderflapper mangler, eller det er synlig skade på ballistiske paneler.

GARANTI

10 år fra produksjonsdatoen (se merke påført innsiden av platebærerens).